



TBI-6 IS SIGNAL MODE SELECTABLE AS FOLLOWS:

W3 & W4 POSITION	REMOTE START SIGNAL
A	GND TO START
B	B+ TO START

P2-2&3 ARE FUNCTION MODE SELECTABLE AS FOLLOWS:

P2-2:W7	P2-3:W6	POSITION	FUNCTION MODE
		A	NON-SHUTDOWN
		B	SHUTDOWN

TB2-1&3 ARE FUNCTION MODE SELECTABLE AS FOLLOWS:

TB2-1:W1	TB2-3:W2	POSITION	FUNCTION MODE
		A	NON-SHUTDOWN, NON-TIMED
		B	SHUTDOWN, NON-TIMED
		C	NON-SHUTDOWN, TIMED
		D	SHUTDOWN, TIMED

## NOTES:

\* THESE CIRCUITS RATED 500ma MAX AND ARE FOR REMOTE ANNUNCIATOR USE.

1. ALL GROUND INPUTS OTHER THAN BATTERY GROUND ARE OF THE SWITCHING TYPE, (i.e. SENDER OR RELAY CONTACT BETWEEN THE INPUT AND GROUND).
2. ALL GROUND OUTPUTS ARE SWITCHING TYPE, (i.e. THE OUTPUT SWITCHES ON THE GROUND SIDE OF REMOTE LAMP OR RELAY).

FIGURE 3-3 ENGINE CONTROL MONITOR