

Description	One Link Function	I/O Cable	Location	Generator Function
Battery +	Battery +	Red	Battery +	Battery +
Battery -	Battery -	Black	Battery -	Battery -
K1COM	K1COM	Red/White	Remote Start Contact	Remote Start
K1NO	K1NO	Red/Black	Remote Start Contact	Remote Start
K2COM	K2COM	Orange		
K2NC	K2NC	Orange/Black		
DI1	Close to Ground	Black/White		
DI2	Close to Ground	Blue/Black		
DI3	Close to Ground	Blue/White		
DI4	Close to Battery +	Blue		
DI5	Close to Battery +	Green/Black		
DI6	Close to Battery +	Green		
A1	0-5V	Green/White		
A2	0-5V	White		
L1	AC Voltage L1	White/Black	S15 (Back of HZ Meter)	AC Voltage Sensing
L2	AC Voltage L2	Red	S16 (Back of HZ Meter)	AC Voltage Sensing